



1/2

Fig. 1



1 { 21 22
RP::

Fig. 2



30 { default: 8s 111111/8s
222222/333333
workday 0700-0800: 8s
222222/333333 } 31
workday 0800-1700: 5s
444444/5s 222222
5s 555555/333333
...




Fig. 3

Fig. 4

Mobile station
user interface

Mobile station
basic functionality

MEXE

Mobile station
basic functionality

MSC

SCP




Fig. 5

Mobile station
user interface

Mobile station
basic functionality

MEXE

Mobile station
basic functionality

MSC

SCP

